2.2 Potentiometers

Introduction

A potentiometer is a three-terminal resistor with a sliding or rotating contact that forms an adjustable voltage divider.

NEER

• Commonly used for adjusting levels, such as volume control in audio equipment.

Types of Potentiometers

- 1. Rotary Potentiometer: Has a knob that rotates to adjust resistance.
- 2. Linear Potentiometer: Has a slider that moves linearly to adjust resistance.
- 3. **Digital Potentiometer:** Adjusts resistance electronically, often controlled by microcontrollers.

Construction

- Resistive Element: A strip of resistive material (carbon, cermet, wire).
- Wiper: A movable contact that slides over the resistive element.
- Terminals: Three terminals: two connected to the ends of the resistive element, and one connected to the wiper.

Working Principle

- The potentiometer divides the input voltage based on the position of the wiper.
- The voltage at the wiper (output) is a fraction of the total voltage applied across the end terminals.
- The position of the wiper determines the resistance between the wiper and the end • terminals, thus varying the output voltage. M, KANYAKUN

Circuit Diagram

plair Copy					
+V	(Input	Voltage)			
		<u> </u>	RVS ODTINE	ZE OUTSPREA	· • •
	R1			TE MALLER.	
	1		utput Voltage)		
	R2				
Gro	ound				

Where R1 and R2 are variable resistances determined by the position of the wiper.

Applications

- Volume Control: Adjusting audio levels in radios and amplifiers.
- **Position Sensing:** In joysticks, servos, and other control devices.

ROHINICOLLEGEOFENGINEERING&TECHNOLOGY

- Adjustable Power Supplies: Setting voltage or current levels.
- Calibration: Fine-tuning circuits in test and measurement equipment.

Advantages

- Simple and easy to use.
- Provides continuous adjustment.
- Available in a wide range of sizes and resistance values.

Disadvantages

- Mechanical wear over time.
- Limited resolution compared to digital counterparts.
- Potential noise due to wiper movement.

Error Sources

- Mechanical Wear: Leads to inaccuracy and noise over time.
- Temperature Variations: Can affect the resistance value and stability.
- Contact Resistance: Variable contact resistance can introduce noise and non-linearity.

Error Analysis

- Mechanical Precision: High-quality materials and construction reduce wear and improve lifespan.
- Temperature Compensation: Use materials with low temperature coefficients.
- Regular Maintenance: Periodically clean and inspect potentiometers to ensure accuracy.

Maintenance and Calibration

- Regular inspection for mechanical wear and cleanliness.
- Periodic calibration to ensure accurate output.
- Replace worn or damaged potentiometers to maintain performance.

Summary

OBSERVE OPTIMIZE OUTSPRI

Potentiometers are versatile components used for variable resistance and voltage division in a variety of applications. Understanding their construction, working principles, and potential error sources is essential for effective usage and maintenance.