

LOAD FACTOR

Load factor

The ratio of the collapse load to the working load is termed as load factor. It is represented by 'F'; and is similar to factor of safety in the elastic design. The load factor is expressed as

$$F = P_u / P_w$$

Where,

P_u – Collapse load

P_w – Working load

